



Installing the USB-Serial Converter Driver

1. Navigate into the **prolific serial driver** folder
2. Run (double click) on **SETUP** to launch the installation
3. The Following screen will come up.



4. Click **Next>** and the installation program will install the needed USB-Serial Converter driver.



5. Installation has completed. You can click **Finish**.